

HUSHING BROOKS ALARMS



STEP 1

CHECK FOR FIRE

If there is a fire evacuate immediately and call 000. If there is no fire, proceed to step 2.



STEP 2

FIND INITIATING SMOKE ALARM WITH FLASHING RED LIGHT



STEP 3

PRESS HUSH BUTTON ON INITIATING ALARM TO SILENCE ALL SMOKE ALARMS

Press and hold for one second.

YOU SHOULD NOT NEED TO PHYSICALLY REMOVE THE ALARM FROM THE CEILING

NEXT STEPS

- If more than one alarm has a flashing red light the test/hush button may need to be pressed on these alarms as well for all alarm to hush.
- After pressing the test/hush button *BE PATIENT* you will need to wait for all the alarms to stop sounding.. this can take several minutes.
- The alarms will then be in hush mode and if there is still smoke in the air the alarms may trigger again in 10 minutes. Keep using the test/hush button until the smoke has cleared.
- Sometimes other things trigger the alarm such as humidity, insects or dust and can get trapped in the alarm causing them to trigger when there isn't smoke. In this case you can remove each alarm from the ceiling and clean it with a standard household vacuum.

REMOVING MOST COMMON BROOKS ALARM TYPES FROM CEILING



Removing EIB2016 & EIB146RC from ceiling base plate.

- Turn off the house power.
- At side of alarm locate removal slot and insert flat screwdriver.
- With screwdriver still inserted push lower half of alarm away from screwdriver in direction of arrows on cover.
- Holding lower half of alarm remove it from base plate by lowering towards floor.
- Take out 9 V battery
- Contact your agent to advise them you have taken an alarm down.



Removing EIB650IRF (or) EIB650IC from ceiling base plate.

- Twist anticlockwise.
- Removing the alarm from its base plate turns it off manually.
- Contact your agent to advise them you have taken an alarm down

Check Systems Customer Support: 1300 074 225
Customer support available 9:00am to 5:00pm (AEST) Monday to Friday.